CARE & MAINTENANCE

Collection:	Terra
Pattern:	Chimu
Reference:	23903 • Olive
Composition:	3D textile wallcovering on non-woven backing
Description:	This vibrant pattern was inspired by the ancient
	stone carvings of the Chimú culture in pre-
	Colombian Peru. The realistic stone look provides
	the perfect base for these mythological creatures.

During installation:



Carefully dab off any adhesive stains immediately (before the adhesive has dried) with clean water and a soft cloth. Do this after installation of each length.

Maintenance:

First try to apply in an inconspicuous place. Try to remove any stains immediately, before the stain can dry out, by dabbing off the surface with a moist, lint-free, clean white cloth. Only use clear water, no soap.

Avoid excessive rubbing of the surface. Avoid excessive soaking of the surface.

Dust can be wiped off with a damp, lint-free, clean cloth or a brush with soft bristles, or can be lightly vacuumed with a soft bristle attachment to avoid damaging the surface.

Arte can not be held responsible if damage is caused to the product during the cleaning process.



More info? <u>Click here</u>



-ARTE[®]

wallcoverings for the ultimate in refinement