## CARE & MAINTENANCE

Collection: Pattern: Reference: Composition: Description: Essentials Tangram Caprice 24004 • Linen Wallpaper on non-woven backing Very finely woven grasses, cut and inlaid by hand, are the inspiration for this design. The playful, irregular pattern of straight and rounded corners creates an artistic effect.



## During installation:



Carefully wipe off any adhesive stains immediately (before the adhesive has dried) with clean water and a soft sponge. Do this after installation of each length.

## Maintenance:

First try to apply in an inconspicuous place. Try to remove any stains immediately, before the stain can dry out, by whiping off the surface with clean water and a soft sponge. Only use clear water, no soap.

Dry with a lint-free, clean cloth.

Avoid excessive rubbing of the surface. Avoid excessive soaking of the surface.

Dust can be wiped off with a damp, lint-free, clean cloth or a brush with soft bristles, or can be lightly vacuumed with a soft bristle attachment to avoid damaging the surface.

Arte can not be held responsible if damage is caused to the product during the cleaning process.



More info? <u>Click here</u>



## -ARTE<sup>®</sup>

wallcoverings for the ultimate in refinement