


# CARE & MAINTENANCE

---

Collection:	Emblème
Pattern:	Coti
Reference:	30800 • Fire Orange
Composition:	Natural wallcovering on non-woven backing
Description:	'Bois coti' is the French term for spalting or flamed wood, like the wood in this design. Coti is completely at home in bold and arresting interiors. Made from beautiful flamed wood veneer and inlaid in a block pattern, this is the kind of wallcovering that warrants a second look.



---

## During installation:



Carefully dab off any adhesive stains immediately (before the adhesive has dried) with clean water and a soft cloth. Do this after installation of each length.

---

## Maintenance:

First try to apply in an inconspicuous place. Try to remove any stains immediately, before the stain can dry out, by dabbing off the surface with a moist, lint-free, clean white cloth. Only use clear water, no soap.

Avoid excessive rubbing of the surface. Avoid excessive soaking of the surface.

Dust can be wiped off with a damp, lint-free, clean cloth or a brush with soft bristles, or can be lightly vacuumed with a soft bristle attachment to avoid damaging the surface.

---

Arte can not be held responsible if damage is caused to the product during the cleaning process.



More info? [Click here](#)



---

ARTE®

wallcoverings for the ultimate in refinement