

CARE & MAINTENANCE

Collection:	Artisan
Pattern:	Drift
Reference:	40314 • Turquoise
Composition:	Natural wallcovering on non-woven backing
Description:	Made from natural sisal fibres which are very finely woven. The woven sisal is then hand-pleated. Finally, we use the tipping technique, in which metallic ink is applied to the tips of the pleats. This yields a living, totally unique wallcovering, brimming with character.

During installation:



Carefully dab off any adhesive stains immediately (before the adhesive has dried) with clean water and a soft cloth. Do this after installation of each length.

Maintenance:

First try to apply in an inconspicuous place. Try to remove any stains immediately, before the stain can dry out, by dabbing off the surface with a moist, lint-free, clean white cloth. Only use clear water, no soap.

Avoid excessive rubbing of the surface. Avoid excessive soaking of the surface.

Dust can be wiped off with a damp, lint-free, clean cloth or a brush with soft bristles, or can be lightly vacuumed with a soft bristle attachment to avoid damaging the surface.

Arte can not be held responsible if damage is caused to the product during the cleaning process.



More info? [Click here](#)



ARTE®

wallcoverings for the ultimate in refinement