## Care & Maintenance

Collection: Osmanthus Pattern: Sambe

Reference: 54550 · Natural White

Natural wallcovering on non-woven backing Composition: Description: This design is made of hemp fibres whose natural

colours contrast with the fine black yarns that hold the fibres together. The knots and irregular threads of different thicknesses are clearly

and pure.



## During installation:



Carefully dab off any adhesive stains immediately (before the adhesive has dried) with clean water and a soft cloth. Do this after installation of each length.

## Maintenance:

First try to apply in an inconspicuous place. Try to remove any stains immediately, before the stain can dry out, by dabbing off the surface with a moist, lint-free, clean white cloth. Only use clear water, no soap.

Avoid excessive rubbing of the surface. Avoid excessive soaking of the surface.

Dust can be wiped off with a damp, lint-free, clean cloth or a brush with soft bristles, or can be lightly vacuumed with a soft bristle attachment to avoid damaging the surface.

Arte can not be held responsible if damage is caused to the product during the cleaning process.





