


CARE & MAINTENANCE

Collection:	Spectra
Pattern:	Carrelage
Reference:	61513
Composition:	3D textile wallcovering on non-woven backing
Description:	With Carrelage you do not have to do major remodelling to put tiles on the wall. As the name suggests, this design comes very close to authentic tile work. The varying pattern brings the three-dimensional look into your home in a playful manner.



During installation:



Carefully dab off any adhesive stains immediately (before the adhesive has dried) with clean water and a soft cloth. Do this after installation of each length.

Maintenance:

First try to apply in an inconspicuous place. Try to remove any stains immediately, before the stain can dry out, by dabbing off the surface with a moist, lint-free, clean white cloth. Only use clear water, no soap.

Avoid excessive rubbing of the surface. Avoid excessive soaking of the surface.

Dust can be wiped off with a damp, lint-free, clean cloth or a brush with soft bristles, or can be lightly vacuumed with a soft bristle attachment to avoid damaging the surface.

Arte can not be held responsible if damage is caused to the product during the cleaning process.



More info? [Click here](#)



ARTE®

wallcoverings for the ultimate in refinement