CARE & MAINTENANCE

Collection: Kanso Pattern: Iki

Reference: 72513 • Ecru

Composition: 3D textile wallcovering on non-woven backing

Description: "Iki", a concept that is difficult to translate into a

single word, embraces a world of sophistication, elegance, simplicity and a deep appreciation for the

beauty in everyday things. "Iki" becomes tangible in this design, with diagonal lines creating a beautifully magnified herringbone pattern. The distance between these lines is expressively uneven, giving a playful and dynamic feeling to the wall. The pronounced texture lends it a captivating 3D effect, while the top layer in soft velvet adds a touch of luxury, making it almost impossible not to want to touch the wall.



During installation:



Carefully dab off any adhesive stains immediately (before the adhesive has dried) with clean water and a soft cloth. Do this after installation of each length.

Maintenance:

First try to apply in an inconspicuous place. Try to remove any stains immediately, before the stain can dry out, by dabbing off the surface with a moist, lint-free, clean white cloth. Only use clear water, no soap.

Avoid excessive rubbing of the surface. Avoid excessive soaking of the surface.

Dust can be wiped off with a damp, lint-free, clean cloth or a brush with soft bristles, or can be lightly vacuumed with a soft bristle attachment to avoid damaging the surface.

Arte can not be held responsible if damage is caused to the product during the cleaning process.



NEUTRAL SULFR COMPANY.

NEUTRAL SULFR COMPANY.

NEUTRAL SULFR COMPANY.

