

# CARE & MAINTENANCE

---

Collection:	Kharga
Pattern:	Ténéré
Reference:	74020 • Prairie Sand
Composition:	Non-woven wallcovering
Description:	Ténéré, an area in the southern Sahara, is known as one of the driest deserts in the world. The dehydrated and cracked desert soil forms the inspiration for this lacquered imitation leather.



---

## During installation:



Carefully dab off any adhesive stains immediately (before the adhesive has dried) with clean water and a soft cloth. Do this after installation of each length.

---

## Maintenance:

First try to apply in an inconspicuous place. Try to remove any stains immediately, before the stain can dry out, by dabbing off the surface with a moist, lint-free, clean white cloth. Only use clear water, no soap.

Avoid excessive rubbing of the surface. Avoid excessive soaking of the surface.

Dust can be wiped off with a damp, lint-free, clean cloth or a brush with soft bristles, or can be lightly vacuumed with a soft bristle attachment to avoid damaging the surface.

---

Arte can not be held responsible if damage is caused to the product during the cleaning process.



More info? [Click here](#)



ARTE®

wallcoverings for the ultimate in refinement