

CARE & MAINTENANCE

| | |
|--------------|--|
| Collection: | Icons |
| Pattern: | Curve |
| Reference: | 85552 • Petrol |
| Composition: | 3D textile wallcovering on non-woven backing |
| Description: | Round, soft shapes with a hint of vintage, incorporated into a subtle grid, this describes Curve best. The textile is made of a warm 3D bouclé fabric. |



During installation:



Carefully dab off any adhesive stains immediately (before the adhesive has dried) with clean water and a soft cloth. Do this after installation of each length.

Maintenance:

First try to apply in an inconspicuous place. Try to remove any stains immediately, before the stain can dry out, by dabbing off the surface with a moist, lint-free, clean white cloth. Only use clear water, no soap.

Avoid excessive rubbing of the surface. Avoid excessive soaking of the surface.

Dust can be wiped off with a damp, lint-free, clean cloth or a brush with soft bristles, or can be lightly vacuumed with a soft bristle attachment to avoid damaging the surface.

Arte can not be held responsible if damage is caused to the product during the cleaning process.



More info? [Click here](#)



ARTE®

wallcoverings for the ultimate in refinement