CARE & MAINTENANCE

Collection: Pattern: Reference: Composition: Description: Icons Symbiosis 85560 • White Gold Non-woven wallcovering An eclectic mix of intriguing, graceful images. Plants, plumes and rattan form a beautiful symbiosis and stimulate your imagination. Which is it: strikingly subtle or subtly striking? This design is available with a soft metal accent as well as an explicit high-gloss.



During installation:



Carefully wipe off any adhesive stains immediately (before the adhesive has dried) with clean water and a soft sponge. Do this after installation of each length.

Maintenance:

First try to apply in an inconspicuous place. Try to remove any stains immediately, before the stain can dry out, by whiping off the surface with clean water and a soft sponge. Only use clear water, no soap.

Dry with a lint-free, clean cloth.

Avoid excessive rubbing of the surface. Avoid excessive soaking of the surface.

Dust can be wiped off with a damp, lint-free, clean cloth or a brush with soft bristles, or can be lightly vacuumed with a soft bristle attachment to avoid damaging the surface.

Arte can not be held responsible if damage is caused to the product during the cleaning process.



More info? <u>Click here</u>



-ARTE®

wallcoverings for the ultimate in refinement