CARE & MAINTENANCE

Collection: Kami
Pattern: Origami
Reference: 87220

Composition: Non-woven wallcovering

Description: The imitation of folded paper reflects the ripple of

moving water. The pleats create a lot of relief and the repetitive nature brings peace and regularity. The luxurious finish of the top layer is a silk gloss

ink with an elegant silk look as a result.



During installation:



Carefully dab off any adhesive stains immediately (before the adhesive has dried) with clean water and a soft cloth. Do this after installation of each length.

Maintenance:

First try to apply in an inconspicuous place. Try to remove any stains immediately, before the stain can dry out, by dabbing off the surface with a moist, lint-free, clean white cloth. Only use clear water, no soap.

Avoid excessive rubbing of the surface. Avoid excessive soaking of the surface.

Dust can be wiped off with a damp, lint-free, clean cloth or a brush with soft bristles, or can be lightly vacuumed with a soft bristle attachment to avoid damaging the surface.

Arte can not be held responsible if damage is caused to the product during the cleaning process.





